

Media Control Station³

9 Pin Version



User's Manual First Edition
©1999-2002 JLCooper Electronics
142 Arena Street • El Segundo, CA 90245 U.S.A

JL COOPER ELECTRONICS

MCS, Media Control Station, MCS³, and Media Control Station³ are trademarks of JLCooper Electronics. All other brand names are the property of their respective holders.

MCS³ 9 Pin User's Manual First Edition

Part Number for this manual is 932076-9pin

©1999 -2002 JLCooper Electronics • 142 Arena Street • El Segundo, CA 90245 U.S.A.

(310)322-9990

(310)322-0110 fax

www.jlcooper.com

Table of Contents

Introduction.....	4
Connecting the MCS³	5
Features and Operation	6
Transports	6
V-Stick	6
Jog Mode	7
Shuttle Mode	7
Shuttle LEDs	7
Locate	8
Track Arming Analog or Digital Machines ...	9
Track Number Shifting	9
Track Mapping	10
Technical Information	11
MCS ³ as Computer Controller	11
Specifications	11
Care and Service	11
Warranty	12

Introduction

The JLCoper Media Control Station³ is a remote control for VTRs and other machines that support Sony 9 Pin "P2" protocol.

The MCS³ controls professional analogue and digital VTRs, modular digital multitracks, and disk-based VTR emulators.

The MCS³ can also operate in certain applications as a control station "input device" for computer-based editing systems.

The MCS³ features a smooth, weighted and optically encoded jog shuttle wheel with concentric shuttle ring, and transport and function keys.

As shipped from the factory, the MCS³ is normally configured and "ready to use" as a VTR controller.

When the MCS³ is intended to be used as an input device for a computer editing system, it will need to be reconfigured internally. Instructions for doing this are provided at the end of this manual.

This manual relates to the features and operation of the MCS³ as a 9 Pin/2 controller. If the MCS³ is used as an input device to a computer-based system, follow the instructions included with the system.

Please take a moment to send in your product registration card, so we can notify you in the future about any new products or updates as they become available.

Connecting the MCS³

Connect the supplied external power supply to the power jack on the MCS³'s captive cable.

In case a replacement supply is used, see to it that it has the same rating as the original supply: The power supply's output is rated at 9 volts DC, 500 mA, with a center positive 2.1 mm plug.

Connect MCS³ 9 Pin cable to the 9 Pin remote input of the machine that you are controlling.

Features and Operation

Transport Functions

The Transports control Rewind, Fast Forward, Stop, Play, and Record. Pause is enabled by pressing the button marked W7.

The Record button is interlocked with the Play button. To enable Record, you must hold down one and push the other.

Record only operates if tracks have been enabled (“armed”) first. (See Track Enabling below.)

To Record, first arm tracks. Then press and release Play, and allow the machine to come up to speed.

Then press Play again and hold it down. While holding down Play, press Record.

Then release both switches.

While in Record mode, the pressing of the Play button send a Record Exit command, dropping the controlled unit out the record state.

V-Stick Functions

The “V/Stick” is located to the upper right of the jog/shuttle control. It is a soft, four position switch.

The switch is activated by applying pressure either left, right, toward you, or away from you. (It is not necessary to press down or rotate the control.) It performs the following functions:

- V-Stick Down = Reverse 2x Speed
- V-Stick Up = Forward 2x Speed
- V-Stick Left = Reverse 1x Speed
- V-Stick Right = Forward 1x Speed

Jog Mode

The center wheel is for Jog mode. In Jog mode, playback speed and direction is proportional to the speed and direction that the wheel is rotated.

Rotate the wheel clockwise for forward playback.

Rotate the wheel counter clockwise for reverse playback.

In Jog mode, continuously rotating the wheel results in 1X play speed, either forward or backward.

To stop the tape, simply stop turning the wheel.

Shuttle Mode

The outer ring is for Shuttle mode. In Shuttle mode, playback speed is related to the extent of rotation away from the starting position of the wheel.

Rotate the ring clockwise for forward shuttle.

Rotate the ring counter clockwise for reverse shuttle.

The program continues to shuttle until the ring is returned to its center position. Alternately, simply press Stop.

Shuttle LEDs

Normally, on power up, the shuttle ring LEDs will not light until the shuttle ring is centered.

After that, the shuttle ring LEDs will light depending upon the direction of rotation from center. Both LEDs are on when the ring is centered.

Locate Functions

The MCS³ may be “taught” locations either on the fly (program is playing) or while stationary (program is stopped.)

Locates are stored by pressing and holding the Record button, and while holding the Record button, press W1 thru W6.

A location request will be sent, and the response stored within the MCS³. This will be remembered until power is removed from the MCS³.

The MCS³ stores six locate points:

- W1 Locate 1
- W2 Locate 2
- W3 Locate 3
- W4 Locate 4
- W5 Locate 5
- W6 Locate 6

Track Arming Analog or Digital Machines

The MCS³ can send the appropriate commands for track arming analog or digital machines.

The unit normally is configured for digital track arming.

To change modes, press and hold down buttons F5 and F6 at the same time.

While holding down F5 and F6, press F2 to change to analog mode.

While holding down F5 and F6, press F1 to return to digital mode.

Track Number Shifting

Function Keys F1 - F4 can be used to arm tracks 1 - 4, and

Function Keys F5 - F8 can be used to arm tracks 5 - 8.

Function Keys F5 & F6 act as track number "shift buttons".

For example,

F1 through F4 toggle the track arming state of tracks 1 - 4.

Press and release F6:

F1 through F4 now toggle the track arming state of tracks 5 - 8.

Press and release F5:

F1 through F4 now toggle the track arming state of tracks 1 - 4 again.

Be aware that the MCS³ has no knowledge of any track enabling done on the front panel of the VTR machine itself. Nor does it know the status of the machine when the MCS³ is first powered on. The MCS³ powers-up operating under the assumption that all tracks are not enabled.

Analog Machine Track Mapping

Actual mapping of tracks to audio/video is machine dependent, and should be confirmed before doing any real editing.

Typically, the mapping is:

Track 1- Audio Track 1

Track 2- Audio Track 2

Track 3- Time Code

Track 4- not used

Track 5- Video

Track 6- Assemble

Track 7- Insert

Track 8- not used

Technical Information

MCS³ as Computer Controller

The RS-422/P2 MCS³ can operate in either of two modes, either as a stand-alone Master Controller for machines that respond to the so-called "P2" format, or as a "Slave RS-422 device" meant to be attached to a Master Host. This generally means that the MCS³ is a control station for a computer-based editing system.

As shipped from the factory, the MCS³ is normally configured as a Master device, but is easily re-configured for "Slave/Host" mode to act as a computer input device. To do so, a 5/64" Allen wrench and a small flat-blade screwdriver are needed.

- (1) Remove the four screws from the front.
- (2) Carefully slide the cable's strain relief from its slot on the unit bottom.
- (3) On the small circuit board, remove the 8-pin IC which is inserted into U3 "To Mach." and move it over to the "To Host" socket. Make sure orientation is preserved.
- (4) Remove the jumper JB1. Store the jumper by placing it over only one pin of JB1.
- (5) Carefully re-insert the strain relief, dress the inside section of cable away from the sensitive Jog Wheel assembly, and re-insert the four screws.

Specifications

Dimensions:6.5" X 7" X 1.25"

Shipping Weight3.7 lbs.

Care and Service

If properly cared for, your MCS³ should provide years of trouble-free performance. Avoid dropping the MCS³, or hard banging on the keys.

Clean with a soft cloth dampened with window cleaner. Do not allow liquids to get inside the unit.

There are no user-serviceable parts in the MCS³. Please refer to the really fine print following for detailed warranty and service information.

JLCooper Electronics Limited Factory Warranty

JLCooper Electronics ("JLCooper") warrants this product to be free of defects in materials or workmanship for a period of 12 months from the date of purchase.

This warranty is non-transferable and the benefits apply to the original owner. Proof of purchase in the form of an itemized sales receipt is required for warranty coverage.

To receive service under this warranty, customers in the United States should contact the JLCooper factory at (310) 322-9990 and talk to a service technician. If necessary, a Return Authorization number may be issued.

For our customers outside the United States, it is recommended that you first contact your Dealer or Distributor, since they may offer their own service or support policy.

If local support is not obtainable, please send a FAX to JLCooper's Service Department at (310) 335-0110, with a detailed description of the service required.

Upon issuance of return authorization, the product should be properly packed and shipped to Service Department, JLCooper Electronics, 142 Arena St., El Segundo, CA 90245.

Please include the following: copy of the sales receipt, your name and address (no P.O. Boxes, please), a brief description of the problem, and any other related items discussed with the service department and considered necessary to evaluate the product or effect a repair. The return authorization number must be clearly written on the outside of the package.

JLCooper will, without charge for parts or labor, either repair or replace the defective part(s). Shipping costs are not covered by this warranty.

JLCooper's normal repair turn around time at the factory is approximately 15 business days, from receipt of product to shipping. Your actual turn around time will include return shipping.

Actual turn around time will vary depending upon many factors including the repeatability of the customer's reported complaint, the availability of parts required for repair, the availability of related products needed to evaluate the product if necessary.

Priority services are available. These should be discussed with the service technician at the time the return authorization is issued.

This warranty provides only the benefits specified and does not cover defects or repairs needed as result of acts beyond the control of JLCooper including but not limited to: abuse, damage by accident/negligence, modification, alteration, improper use, unauthorized servicing, tampering, or failure to operate in accordance with the procedures outlined in the owner's manual; nor for acts of God such as flooding, lightning, tornadoes, etc.

THE DURATION OF ANY OTHER WARRANTIES, WHETHER IMPLIED OR EXPRESS, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTY OF MERCHANTABILITY, IS LIMITED TO THE DURATION OF THE EXPRESS WARRANTY HEREIN. JLCOOPER HEREBY EXCLUDES INCIDENTAL AND CONSEQUENTIAL DAMAGES, INCLUDING BUT NOT LIMITED TO: LOSS OF TIME, INCONVENIENCE, DELAY IN PERFORMANCE OF THIS WARRANTY, THE LOSS OF USE OF THE PRODUCT OR COMMERCIAL LOSS, AND FOR BREACH OF ANY EXPRESS OR IMPLIED WARRANTY OF MERCHANTABILITY, APPLICABLE TO THIS PRODUCT. JLCOOPER SHALL NOT BE LIABLE FOR DAMAGES OR LOSS RESULTING FROM THE NEGLIGENT OR INTENTIONAL ACTS OF THE SHIPPER OR HIS CONTRACT AFFILIATES. THE CUSTOMER SHOULD CONTACT THE SHIPPER FOR PROPER CLAIMS PROCEDURES IN THE EVENT OF DAMAGE OR LOSS RESULTING FROM SHIPMENT.